

WeatherTech®

PlateFrame™ Installation Instructions

Hardware Included

License Plate Frame
Stainless Steel Fastener Universal Kit
Click and Stay™ Screw Caps

Tools Needed

You will need a #2 Phillips screw driver and 7/16" Wrench to complete this installation.

- 1) Remove the Click and Stay™ screw covers from the mounting holes in the WeatherTech® PlateFrame™ by pushing them out from the back side.
- 2) Lay the WeatherTech® PlateFrame™ face down on a soft or non-abrasive surface.
- 3) Position the license plate face down onto PlateFrame™, lining up the holes in the plate and the holes in the frame. Make certain that you have a proper fit between the license plate and the PlateFrame™.
- 4) Select the four mounting screws that are most appropriate for your vehicle (If your mounting location only uses 2 holes, then see step 4A FIRST). Carefully position your PlateFrame™ / license plate assembly into place on your vehicle and using a #2 Phillips Head screwdriver, securely fasten with the screws you have chosen, BEING CAREFUL NOT TO OVER-TIGHTEN.

(4A) If the mounting location on your vehicle only uses two screws, then first select machine screws and matching nuts from the hardware pack. Install these two screws through the PlateFrame™ / license plate assembly in the holes that DO NOT go to the mounting holes on the vehicle. Using a #2 Phillips Head screwdriver and a wrench, tighten the two nuts onto the end of each screw, locking the assembly together, BEING CAREFUL NOT TO OVER-TIGHTEN.

- 5) Finally, position the Click and Stay™ screw covers over each screw on your PlateFrame™ with the drain hole on the bottom and push firmly to snap each one into place.



Questions: Please contact us at MacNeil Automotive Products Ltd.
or visit our website at www.WeatherTech.com