

WeatherTech® TechShade™ Installation Instructions

⚠ WARNING ⚠

Never operate the vehicle with the TechShade™ installed in the windshield. It is only intended for parked vehicle use.



1. Remove your TechShade™ from the carton and unroll to install in your windshield. Please note that the cutout in the center part is for clearance around the rear view mirror.



2. For protection against the sun and interior heat, please install the reflective material mirror-side facing outward. For colder temperatures, please install with the black side facing outward to absorb the sun's rays.



3. The suction cups are designed to ensure installation regardless of temperature, and are easily reversible by pinching the release-end and squishing it through the retaining ring. The unique design of the suction cup allows for ease of removal, and the Velcro tab allows for secure storage of the TechShade™ when rolled-up and not in use.

HELP!

If you have any questions regarding installation or use of your WeatherTech® Product, please call our Customer Service Department at (630) 769-1500, Monday through Friday, 9 a.m. to 5 p.m. Central Time. We want to help you get the most out of your new WeatherTech® Product.

2435 Wisconsin Street • Downers Grove • IL • 60515
phone (630) 769-1500 • (800) 441-6287 • fax (630) 769-0300
www.weathertech.com • sales@macneil.com

MacNeil
AUTOMOTIVE
PRODUCTS LIMITED