

WeatherTech®

Automotive Accessories

Cargo Liner Fitting Instructions:

Your new WeatherTech® Cargo Liner is custom molded to fit your particular vehicle. Upon removal from the box you will notice that the liner will not completely unroll and lay flat. This is normal and only temporary. Just place the liner on the floor or in the back of your vehicle and put a weight in each corner (a book works well). After about 15 minutes your liner will remain flat. Your liner is made from an engineered resin that is both lightweight and extremely tough and durable. The easiest way to clean your liner is with a damp cloth or sponge. If using a cleaner, 409® or Glass Plus® work well. We do not recommend Armor-All® or Son-of-a-Gun® as these types of products make the liner slick and cargo will slide.

HELP!! If you have questions regarding installation of this or any other WeatherTech® product, please call our customer service department at (630) 769-1500, Monday through Friday, 9 a.m. to 5 p.m. central time. We want to help you get the most out of your new WeatherTech® product. Please visit our website at www.WeatherTech.com

